



---

## PROROC® LITE ALL-PURPOSE PAIL

PROUDLY OFFERED BY YOUR LOCAL [KNEZ BUILDING MATERIALS SUPPLIER](#).

### OVERVIEW

ProRoc® Brand Joint Compounds are pre-mixed vinyl based compounds that need only minimal thinning or mixing. ProRoc® Brand Joint Compounds deliver a smooth, seamless finish for ceilings and walls, when used correctly.

Please see the [Product Data and Submittal Sheet](#) for complete Technical Data.

### TECHNICAL INFORMATION

Material: Vinyl-type mixture

Color: Off white

Packaging: 4.5 US Gal. (17 L) Pail

Coverage: 100 lb. (45.5 kg) to 150 lb. (68 kg) of joint compound per 1000 square feet (92.9 m<sup>2</sup>) of wallboard depending upon the thickness of joint compound applied.

Shelf Life: 12 months from production code date when stored properly.

Please see the [Product Data and Submittal Sheet](#) for complete Technical Data.

### OTHER RESOURCES:

[Finishing Brochure - US - English](#)

[MSDS - Ready-Mix](#)

### INSTALLATION

#### FINISHING JOINTS:

For best results, apply three layers. After each layer is dry, sand or sponge it smooth prior to the application of the subsequent coat.

Begin by applying a thin layer of compound product to the tapered edge. Press joint tape firmly into the compound, placing it centered over the seam and embed with a broad knife. Ensure that sufficient joint compound remains under the tape to guarantee a proper bond. After it has fully dried, apply a second coat of compound over the first coat and feather out past the first coat. Allow the second coat to thoroughly dry. Evenly spread the final coat over the second coat and feather to form a smooth uniform finish.

#### FINISHING BEADS AND TRIMS:



---

Apply three coats of compound. Apply the first coat to all the bead and trim; properly feather out onto the panel. Wet sand, as necessary. After allowing the compound to dry thoroughly, apply a second coat and feather at least 2” beyond the first coat. Allow the coat to dry completely and wet sand, if necessary. Apply the finishing coat and extend the compound slightly beyond the previous coat. Once the last coat is dry, sand if necessary to provide a smooth surface for subsequent decoration.

#### SANDING:

If necessary, eliminate dust and minimize scuffing the wallboard paper by first sanding with a wet sponge. Remove high spots using as few strokes as necessary. Clean the sponge frequently during use. If dry sanding is required, use 150 grit or finer sand paper. Delicately sand imperfections and be careful to avoid scuffing the paper. Wear a NIOSH approved dust mask and eye protection whenever dry sanding.

#### DECORATION:

Before applying decoration, make sure that all surfaces are thoroughly dry and dust free. Before applying paint, texture, or wallpaper, a good quality drywall primer or an undiluted latex wall paint with a high solids content should be on the surface to be decorated. Heed all product manufacturers’ specific directions for painting and decorating materials.

See [Install Like the Pros Installation Guide](#) or the [Product Data and Submittal Sheet](#) for complete installation instructions.

#### WARRANTY

Since methods and condition of application such as temperature, humidity and over thinning are beyond our control, CertainTeed Gypsum, Inc. (CertainTeed) will not be responsible for the failure of this product when not used according to directions and specifications and accepted standards of procedure inherent in drywall application; or when reasonable allowance is not made by the user for adverse weather and job conditions. However, if this product proves to be defective, maximum liability shall be limited to replacement of the material only or refund of the purchase price. This shall be the full limit whatsoever of CertainTeed’s liability. All claims shall be submitted in writing to CertainTeed within thirty days from the date of discovery. State or federal laws may provide rights in addition to this warranty that cannot be modified or excluded.

PDF: [Finishing Limited Warranty](#)

**Contact Knez Inc. about ordering this product for your next project.**

**(Phone: 503-620-6142)**

